

Charging and Gauging Assemblies and Components


Item#	Description	Part#
1	Complete Assembly 3000# (Includes Gauge)	OH-3000
2	Air Chuck	OH-3002
3	Adapter	OH-3003
4	Swivel Connector	OH-3004
5	Bleeder Valve	OH-3009
6	Gauging & Head Assembly 3000# (Includes Gauge)	OH-3013
7	Head Assembly (No Gauge)	OH-3014
8	Gauging & Head Assembly 5000# (Includes Gauge)	OH-5013
9	Complete Assembly 5000# (Includes Gauge)	OH-5000
10	Valve Extension (For Conv. Top Repairable Accumulator)	T-OH-3015
11	Gauging Head Assembly for Conv. Top Repairable Accumulator	T-OH-3013
12	Charging & Gauging Assembly for Conventional Top Repairable	T-OH-3000
13	1 Quart Charging & Gauging Assembly	OH-QT-3000



OH-302



OH11-501



OH-CG-3013



OH11-502



OH11-503-1